1. Cut two strips of VHB tape to run the length of the mounting rails. Uniformally adhere the tape strips to the top and bottom of the back of each rail without removing the outer backing.

Note: This is the recommended mounting method – concrete screws/anchors may be used at installer's discretion.


2. To ensure proper spacing, place (2) Pages markerboards on the top and bottom rails and align them on wall in the desired mounting location. Mark rail locations on wall.


3. Make sure the concrete is clean and dry, then remove the tape backing and align to the marked location. Press firmly along the length of the rails, attaching them onto the wall.

DO NOT USE FOR 24 HOURS: *The tape's bond strength increases with time – 50% will be achieved after 20 min, 90% after 24 hours.*

4. To mount more rails in a line, place the second set of rails against the previously mounted so ends touch and repeat steps. *Up to four markerboards can be mounted on each set of rails.*

For questions please call us at (616) 396-1142