

DESCRIPTION

ADJUSTABLE HEIGHT TABLE INSTRUCTIONS

NO.

24366-98 - INST

SE

NOTE: WHEN ASSEMBLING THIS TABLE, NOT ALL OF THE PRE-DRILLED HOLES WILL BE USED.

1. PLACE THE TABLE TOP UPSIDE DOWN ON A NON-SCRATCHING SURFACE. PLACE THE "X" BASE ON THE BOTTOM SIDE OF THE TOP AND ALIGN THE LONG LEGS OF THE BASE WITH THE LONG AXIS OF THE TABLE TOP. ALIGN THE HOLES OF THE BASE WITH THE PILOT HOLES IN THE TOP. ATTACH THE "X" BASE TO THE TOP WITH (6) #12 X 7/8" SCREWS.

***NOTE: THE RELEASE CABLE MUST BE ON THE FAR SIDE OF THE FLAT EDGE OF THE TOP (AS SHOWN) OR ON THE SAME SIDE AS THE HEIGHT CONTROL HANDLE.**

2. ATTACH THE RELEASE HANDLE AND (2) CABLE CLAMPS USING THE PILOT HOLES IN THE TOP WITH (4) #8 X 5/8" SCREWS.

3. CAREFULLY TURN THE TABLE ASSEMBLY UPRIGHT. ASSEMBLY OF THE TABLE IS COMPLETE.

