





Base & Wall Hung Filler Assembly Instructions

937610-INST
Rev. B

| | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1. If necessary, cut backsplash, top, front, bottom and toe kick to size. (Not all parts are included in each filler product.)</p>  <p>Backsplash</p> <p>Top</p> <p>Front</p> <p>Bottom</p> <p>Toe Kick</p> | <p>2. Attach angle brackets to front, toe kick and top with #10 x .625" screws. Tighten to a torque of 30-35 in-lbs.</p>  |
| <p>3. Attach the front to the bottom and top and attach the toe kick to the bottom with #10 x .625" screws. Tighten to a torque of 30-35 in-lbs.</p>  | <p>4. Attach assembled filler and backsplash to adjacent cabinet using #10 x .625" screws and brackets attached to filler. Tighten to a torque of 30-35 in-lbs.</p>  <p>Base Filler</p> <p>Wall Hung Filler</p> |

For questions please call us at (616) 396-1142