



Wire Trough Assembly Instructions

128760-INST
Rev. B


1. Place the worksurface upside down on a non-scratching surface. If your product has a welded frame, proceed to Step 2. If your product has an I-Leg frame or bolt on legs, skip to Step 3.



2. Place the wire trough into position on the steel frame. Insert (3) #10 x 2.000" screws through the holes in the trough and the steel frame, and into the pilot holes in the worksurface. Tighten to a torque of 30 to 35 in-lb.



3. Place the wire trough into position on the bottom of the worksurface. Insert (3) #10 x .500" screws through the holes in the trough and into the pilot holes in the worksurface. Tighten to a torque of 30 to 35 in-lb.



4. Carefully flip the table upright onto the feet.



For questions please call us at (616) 396-1142