

CRAFT TABLE ASSEMBLY INSTRUCTIONS

1. Place desk top (A) in horizontal position with bottom side up.
2. Place legs (B) in an upright position and fasten to top with eight (8) 1/4" x 1 3/4" hex head bolts (C) screwed into inserts (D) in top.
3. Place modesty panel (E) in horizontal position with six (6) pre-drilled bracket holes facing up.
4. Set two (2) center brackets (F) in place over six (6) pre-drilled holes with tab facing up. Put six (6) 8 x 5/8 pan head screws (G) through center brackets (F) and into pre-drilled holes in modesty panel (E).
5. Set modesty panel (E) in place with inserts (D) facing holes in legs (B) and center brackets (F) facing top. Put six (6) 1/4" x 1 3/4" hex head bolts (C) through legs (B) into inserts (D) and two (2) 1/4" x 1/2" hex head bolt (H) through center brackets (F) into insert (D) in center of top.
6. Tighten all bolts securely.

