


18"DP HUTCH ADDITION MOUNTING INSTRUCTIONS






NOTE: UNIT / HUTCH SHOWN MAY DIFFER

HARDWARE REQUIRED:

4 - #12 X 5/8" MOD-EEZ SCREWS
(INCLUDED W/ HUTCH UNIT)

TOOLS REQUIRED:

ELECTRIC DRILL / DRIVER
5/32" DRILL BIT
PHILLIPS SCREW DRIVER OR BIT
TAPE MEASURE
RUBBER MALLET



PAGE 1

18"DP HUTCH ADDITION MOUNTING INSTRUCTIONS

STEP #1:

MEASURE AND DRILL 4 HOLES $5/32"$ DIA. x $5/8"$ DP INTO LOW CABINET TOP. SEE DIAGRAM A




DIAGRAM A

18"DP HUTCH ADDITION MOUNTING INSTRUCTIONS

STEP #2:

SCREW THE 4 #12 X 5/8" MOD-EEZ SCREWS INTO THE HOLES THAT WERE DRILLED IN STEP 1. MAKE SURE THE SCREWS ARE SEATED FLUSH TO TOP, SEE DIAGRAM B.




DIAGRAM B

18"DP HUTCH ADDITION MOUNTING INSTRUCTIONS

STEP #3:

PLACE HUTCH ADDITION ON TOP OF LOWER CABINET TOP, FLUSH SIDE TO SIDE AND HUTCH SHOULD OVERHANG BACK BY 1". SEE DIAGRAM C. SLIDE HUTCH ADDITION FORWARD BY PUSHING ON BOTTOM OF HUTCH ADDITION. A RUBBER Mallet MAY BE NECESSARY TO FLUSH UP BACK OF HUTCH ADDITION W/ LOWER CABINET.




DIAGRAM C