



C-Leg Book Box Assembly Instructions

938900-INST
Rev. A


- 1.** Place the worksurface upside down on a non-scratching surface. Place the book box into position on the worksurface (NOTE: C-leg desk shown. Your product may vary.)



- 2.** (If your product has pilot holes, skip to step 3.) Align the book box as shown below and mark the hole locations. Drill (9) 0.125" diameter by 0.500" deep holes.



- 3.** Attach the book box to the worksurface using (9) #8 X 0.625" screws. Tighten to a torque of 30-35 in-lb. (Frame hidden for clarity.)



- 4.** Carefully flip product over to in-use orientation. Completed assembly should look like this. (Your product may vary.)



For questions please call us at (616) 396-1142