


INSTRUCTIONS

**NOTE: BEST TO ASSEMBLE
UNIT ON ITS BACK**



1. ENGAGE SHOULDER SCREWS INTO BACK AND TAP UPWARD TO FLUSH ENDS WITH BACK.
2. INSTALL K-V BRACKETS INTO HOLES PROVIDED TO ATTACH TOP & PARTITION WITH #10 SCREW