



# Library Corner Filler Instructions

81.CF13-INST  
Rev. B


- 1.** These instructions must be completed before assembling any starter or adder shelves. Attach (4) 90-degree brackets with (4) #10 X 0.625" screws to each filler panel. Tighten to a torque of 30-35 in-lbs.




- 2.** Align (1) left hand end panel and (1) right hand end panel from the library shelving assembly. The right hand end panel should overlap the left hand end panel by 0.25".



- 3.** At the top of the end panels, align one filler panel with brackets facing down at the bottom of the edgeband. Screw into the panels using (4) #10 X 0.625" screws. Tighten to a torque of 30-35 in-lbs.



- 4.** Align the second filler panel 4.25" from the bottom of the end panels with brackets facing down. Screw into the end panels using (4) #10 X 0.625" screws. Tighten to a torque of 30-35 in-lbs. Begin the library starter instructions (933710-INST) with the left hand end panel.



For questions please call us at (616) 396-1142