

CRAFT TABLE ASSEMBLY INSTRUCTIONS

1. Place desk top (A) in horizontal position with bottom side up.
2. Place legs (B) in an upright position and fasten to top with eight (8) 1/4" x 1 3/4" hex head bolts (C) screwed into inserts (D) in top.
3. Place modesty panel (E) in horizontal position with three (3) pre-drilled bracket holes facing up.
4. Set center bracket (F) in place over three (3) pre-drilled holes with tab facing up. Put three (3) 8 x 5/8 pan head screws (G) through center bracket (F) and into pre-drilled holes in modesty panel (E).
5. Set modesty panel (E) in place with inserts (D) facing holes in legs (B) and center bracket (F) facing top. Put six (6) 1/4" x 1 3/4" hex head bolts (C) through legs (B) into inserts (D) and one (1) 1/4" x 1/2" hex head bolt (H) through center bracket (F) into insert (D) in center of top.
6. Tighten all bolts securely.

