


MODEL # 43503-99



1. Insert 12 x 5/8 smt screws into end panels.
2. Attach end panels (2) to back by inserting smt screws into mod-eez clips and pounding end panels down to engage clips.
3. Attach tops (2) to unit by inserting smt screws into mod-eez clips and pounding tops inward toward back panel.
4. Install angle brackets (10) & #A9550-100 brackets (4) to tops and back panel with 10 x 5/8 screws.
5. Install support tube #a9550-101 (2) to top using (8) 10 x 2" screws and (4) 10 x 5/8 screws into ends.
6. Insert male and female smt screws (2) into back panel.
7. Attach (2) partitions to back by inserting smt screws into clips and pounding panel down to engage clips. Finish attachment with (6) 10 x 3" screws thru top into bottom of partition.