



INSTRUCTIONS FOR ATTACHING HARMONY CABINETS TOGETHER

**STEP 1: PRE - DRILL END PANELS WITH A 3/8" DRILL BIT.
(3 - HOLES REQUIRED, SEE SKETCH FOR HOLE LOCATIONS)
NOTE: THESE HOLES MUST BE DRILLED ACCURATELY.**

STEP 2: SLIDE CABINETS TOGETHER AND LEVEL CABINETS.

**STEP 3: ATTACH CABINETS TOGETHER WITH:
(3) SLEEVE CONNECTORS (#62800500), INCLUDED IN HARDWARE PACK
(SEE HARDWARE DETAIL)**

HOLE LOCATIONS



**SLEEVE
CONNECTOR**

HARDWARE DETAIL

560000 - 98 - INST