



# Learning Wall Filler Assembly Instructions

941520-INST  
Rev. A


- 1.** If necessary trim top panel, front panel, bottom panel and toe kick to size.




- 2.** Attach (9) brackets to the top panel, (13) brackets to the front panel, and (5) brackets to the toe kick using (27) #10 X 0.625" screws. Tighten to a torque of 30-35 in-lbs.



- 3.** Attach the bottom panel to the front panel and toe kick using (6) #10 X 0.625" screws. Tighten to a torque of 30-35 in-lbs.



- 4.** Attach the top panel to the front panel using (3) #10 X 0.625" screws. Tighten to a torque of 30-35 in-lbs. Attach completed filler to learning wall using remaining #10 X 0.625" screws.



For questions please call us at (616) 396-1142