


CLASSROOM 13" DP HUTCH ADDITION MOUNTING INSTRUCTIONS



HARDWARE REQUIRED:

6 - #12 X 5/8" MOD-EEZ SCREWS
(INCLUDED W/ HUTCH UNIT)

NOTE: UNIT / HUTCH SHOWN MAY DIFFER

TOOLS REQUIRED:

ELECTRIC DRILL / DRIVER
5/32" DRILL BIT
PHILLIPS SCREW DRIVER OR BIT
TAPE MEASURE
RUBBER MALLET

VNTCOMSRV3\SOLIDEDGE\Solid Edge Parts\Class Room Furniture\10.1150-74575\10.1150-74575.asm

PAGE 1

CLASSROOM 13" DP HUTCH ADDITION MOUNTING INSTRUCTIONS

STEP #1:

MEASURE AND DRILL 6 HOLES 5/32" DIA. X 5/8" DP. INTO LOW CABINET TOP.
SEE DIAGRAM A




DIAGRAM A

CLASSROOM 13" DP HUTCH ADDITION MOUNTING INSTRUCTIONS

STEP #2:

SCREW THE 6 - #12 X 5/8" MOD-EEZ SCREWS INTO THE HOLES THAT WERE DRILLED IN STEP 1. MAKE SURE THE SCREWS ARE SEATED FLUSH TO TOP. SEE DIAGRAM B




DIAGRAM B

CLASSROOM 13" DP HUTCH ADDITION MOUNTING INSTRUCTIONS

STEP #3:

PLACE HUTCH ADDITION ON TOP OF LOWER CABINET TOP, OVER PROTUDING CONNECTING SCREWS. HUTCH SHOULD OVERHANG BACK BY 1/2". SEE DIAGRAM C. SLIDE HUTCH ADDITION FORWARD BY PUSHING ON BOTTOM OF HUTCH ADDITION. A RUBBER MALLET MAY BE NECESSARY TO FULLY ENGAGE HUTCH ADDITION W/ LOWER CABINET. ASSEMBLED UNIT SHOULD HAVE 1/2" SPACE IN BACK AND 1 1/2" SPACE ON ENDS.




DIAGRAM C