


# Bag Hook Instruction Sheet

127910-INST  
Rev. A

1. Locate desired position of bag hook along the table frame rails. Hold the hook in place and mark the hole location while making sure that the 90° bend of the hook is tight to the vertical surface of the rail.



2. Drill a pilot hole in the marked location using a 1/8" diameter drill bit. This will ensure that the self-drilling screw goes in easily and in the correct location. Be sure clean up all metal shavings to prevent injury or damage to other products.



3. Attach the bag hook to the rail using the supplied self-drilling screw. Position the screw straight as you drive it in and stop once the screw head is tight to the bag hook. **Do not overtighten the screw.** Overtightening the screw will cause the threads to fail and the attachment will be unreliable.



4. The bag hook is now ready for use. **The load on the bag hook should not exceed 25 lbs.**



For questions please call us at (616) 396-1142