


FLEETWOOD GROUP, INC.


11832 JAMES ST., HOLLAND, MI. P.O. BOX 1259 49422-1259

FURNITURE DIVISION


PHONE (616) 396-1142

MODEL
NO.**56299X.000 - INST**


#10 x 5/8" Pan Head Screw

**DETAIL A**


#10 x 5/8" Pan Head Screw

**DETAIL B**

#10 x 5/8" Pan Head Screw

**DETAIL C**

#8 x 5/8" Pan Head Screw

**DETAIL D**

1. Attach LH back panel (1) to RH back panel (2) with #10 x 5/8" pan head screws (9) (see detail A).

2. Attach LH end (3) to LH back panel (1) with #10 x 5/8" pan head screws (9) (see detail B).

3. Attach RH end (4) to RH back panel (2) with #10 x 5/8" pan head screws (9) (see detail C).

4. Attach top (5) to back panels (1,2) and ends (3,4) with #10 x 5/8" pan head screws (9) (see detail C).

5. Insert shelf clips (10) into back panels (1,2) and RH end (4) and attach shelf (6) with #8 x 5/8" pan head screws (8) (see detail D).


6. Attach shelf support tube to LH back panel (1) and RH end (4) with #10 x 5/8" pan head screws (9) (see detail E).

* If your cabinet was purchased with a door proceed to #7.


7. Attach door (7) to LH end panel (3) with #8 x 5/8" flat head screws (11) (see detail F).

Note: Cabinet must have the end panels attached to the adjacent cabinets or the floor.

#10 x 5/8" Pan Head Screw

**DETAIL E**

#8 x 5/8" Flat Head Screw

**DETAIL F**