




LINE MARK TO EDGE OF DESK




THIS EDGE FLUSH TO EDGE



QUICK CONNECTOR
DETAIL A-A



VIEW OF BACK PANELS



BOTTOM VIEW
OF TOPS

ASSEMBLY INSTRUCTIONS

- Step 1. Attach quick connetors to top in location shown.
Use marks on connectors to line up (See Detail A-A)
- Step 2. Drill 1/8" holes 5/8" deep.
- Step 3. Use #8 x 5/8" FL PH PN Screws to attach connectors to top.
- Step 4. Attach quick connector to lower back panels in location shown.
- Step 5. Repeat steps above to attach to lower back panels.

- TOOLS REQUIRED:**
 ELECTRIC DRILL / DRIVER
 PHILLIPS SCREW DRIVER OR BIT
 TAPE MEASURE
 1/8" DRILL BIT

		SCALE 1:10
FLEETWOOD GROUP, INC.		FURNITURE DIVISION
11832 JAMES ST., HOLLAND, MI. P.O. BOX 1259 49422-1259		PHONE (616) 396-114 FAX (616) 396-8022
DRAWN scottp	CHECKED scottp	DESCRIPTION INSTRUCTOR WORKSTATION (DESK AND RETURN)
DATE 8/14/2007	DATE 8/14/2007	PART NO. 10.XXXX - INST-A