




Mounting Panel Assembly Instructions

942210-INST
Rev. A


- 1.** Position your product in a location where you have easy access to all sides. If your product has locking casters, lock them to prevent movement during assembly. Does your product have pilot holes?




- 2.** Place the Panel Assembly into position on top of the product. The edges of the mounting plate must be a minimum of .375" from all edges of the worksurface. Mark the center of each hole in the mounting plates and drill a 9/64" diameter hole in each location to a depth of .625".



- 3.** Align the holes in the mounting plates with the pilot holes in the top of the product. Insert (8) #12 x .625" screws into the holes and tighten to a torque of 30 to 35 in-lb.



- 4.** The final assembly should look similar to the examples shown here.



For questions please call us at (616) 396-1142