

A

 DRAWN
RD

 CHECKED
LZ

DESCRIPTION


DATE

12/12/05

DATE

12/12/05

HARMONY HANGER ROD INSTRUCTIONS



STEP 1: DETERMINE LOCATION OF HANGER ROD

STEP 2: DRILL PANELS FOR ROD SUPPORT PIN HOLES (5 MM X 3/8 DP.) AND MOUNTING SCREW HOLE (1/8 X 1/2 DP.)

STEP 3: ATTACH ROD SUPPORTS TO PANELS WITH #8 X 5/8 FLAT HEAD SCREWS

STEP 4: INSERT HANGER ROD