

NOTE

ATTENTION INSTALLER:
REMOVE SKID BASE AND
ATTACH CABINET TO FLOOR

- INSTALLER WILL NEED TO SUPPLY FASTENERS TO ATTACH CABINET TO THE FLOOR.
- CABINET MUST BE LEVELED AND LOWER INSIDE DIMENSION HELD AT 34 1/4" BEFORE ATTACHING.