

A

DRAWN

reneed

CHECKED

jeffb

DESCRIPTION

DEMONSTRATOR
MIRROR SETUP

MATERIAL

SCALE

1:4

DATE

11/24/2010

DATE

11/24/2010

SIZE INCH

Demonstrator Mirror Setup

- Unscrew the black knobs from each end of the mirror.
- Slide the aluminum bar clamp assembly off from the bolt on each of mirror.
- Reposition the bar clamp assembly so that the smaller hole (5/16" diameter) is aligned with the bolt and slide back into place. It will touch the mirror frame.
- Screw the black knob back onto each end of mirror.
- The vertical rods used to support the mirror above the cabinet are packed with the cabinet. The vertical rods should be inserted in the larger hole (3/4" diameter) of the bar clamp assembly and into the cabinet countertop.
- Tighten the bolts on the bar clamp assembly to secure the mirror above the cabinet.
- Tighten the black knobs to hold the mirror at the desired viewing angle.

