



84" Wide Computer Table Instruction Sheet

371690-INST
Rev. A



- 1.** Lay table top on clean, non-scratching surface with the pre-drill holes facing up. Place frame onto top and align the holes in the frame with the pre-drill holes. Attach frame to top with (16) #10 X 2" Truss Head Screws and tighten to a torque of 30-35 in-lbs.




- 2.** If your table has adjustable height legs, insert lower legs into upper frame and move to desired height. Fix legs in place by installing (8) 1/4"-20 X .75" screws (2 per leg) through the upper legs and into the threaded holes in the lower legs. Tighten to a torque of 50-60 in-lbs.



- 3.** Attach power management troughs to top using (3) #10 X .625" per trough. Tighten to a torque of 30-35 in-lb.



- 4.** Carefully flip the table over to the in-use position. Install the power grommets into each of the power management holes in the top.



For questions please call us at (616) 396-1142