



Markerboard Cart Assembly Instructions

MB100-INST
Rev. B


1. Unbox the assembly. It will be packed like this.




2. Move the feet into position as shown and insert (2) star locking washers and (2) ¼-20 fasteners for each foot. Tighten to a torque of 75.0-80.0 in-lb.



3. Rotate the tray 90 degrees clockwise and install one #10 screw at each end. Tighten to a torque of 30.0-35.0 in-lb.



4. Completed assembly should look like this.



For questions please call us at (616) 396-1142