



1. Attach end assemblies (2, 3) to back (1) with #10 x 5/8" pan head screws (10)
2. Attach top assembly (4) and bottom assembly (5) to ends (2, 3) and back (1) with #10 x 5/8" pan head screws (10)
3. Attach toe kick (6) to ends (2, 3) and bottom (5) with #10 x 5/8" pan head screws (10)
4. Insert shelf clips and attach shelf (7) to shelf clips with #8 x 5/8 pan head screws (11), then attach support tube brackets to ends (2, 3) with #10 x 5/8 pan head screws.
5. Attach door assemblies (8, 9) to ends (2, 3) with #8 x 5/8" flat head screws (12)

