


A		DRAWN reneeg	CHECKED jeffb	DESCRIPTION Wood Table Leg Permanent Boot Placement Instructions
		DATE 4/27/2010	DATE 4/27/2010	

Items needed:

- Powered Driver with Phillips head bit
- #8 X 1/2" self - tapping screw (provided with the Boots)



Prior to bolting the leg to the frame perform the following steps:

1. Place the boot on the leg.
2. Sliding the boot up and out of the way. On any of the four sides; make a mark approximately 1.75" from the bottom and centered left to right.
3. Take the Powered Driver with Phillips head bit and Screw in the #8 X 1/2" self - tapping screw (provided with the Boots) on the mark.
4. Bolt the leg to the frame and slide the boot over the screw.
5. This method will allow the boot to float up and down without coming completely off when you pick up the table.