


# MODEL # 84.RS-INST



1. Insert (8) #12 x 5/8 shoulder screws into center holes of end panels. (4 per end)  
Install (4) levelers. (2 per end)
2. Attach (1) partition/support panel to (2) end panels by inserting shoulder screws into mod-eez clips and pounding panel down with rubber mallet to engage clips.
3. Attach (1) top with (12) angle brackets using (24) #10 x 5/8 screws. Be sure to index top to ensure that all screw holes are aligned properly.