



Notched U-Trough Assembly Instructions

131250-INST
Rev. B


- 1.** Place the worksurface upside down on a non-scratching surface.




- 2.** Place the wire trough on the underside of the worksurface with the notches facing towards the front of the table. Align the pilot holes with the trough holes.



- 3.** Insert (4 to 6) #10 x .625" screws through the holes in the trough and into the pilot holes in the worksurface. Tighten to a torque of 30 to 35 in-lb.



- 4.** Carefully flip the table upright onto the feet.



For questions please call us at (616) 396-1142