



# Laptop Table Assembly Instructions

935680-INST  
Rev. B


- 1.** Attach the support tube to the base plate with (2) star locking washers and (2) ¼-20 X 1.0" hex bolts. Tighten to a torque of 75-80 in-lb.




- 2.** Set the assembled base upright on the glides.



- 3.** Position the top on the base so the pilot holes line up with the holes in the top plate. Insert (10) #10 X 0.825" screws into the holes. Tighten to a torque of 30-35 in-lb.



- 4.** Completed assembly should look like this.



For questions please call us at (616) 396-1142