


MODEL # 84.- 47671-INST



1. Insert (8) #12 x 5/8 shoulder screws into center holes of end panels. (4 per end)
Install (4) levelers. (2 per end)
2. Attach (1) partition/support panel to (2) end panels by inserting shoulder screws into mod-eez clips and pounding panel down with rubber mallet to engage clips.
3. Attach (1) top with (12) angle brackets using (24) #10 x 5/8 screws. Be sure to index top to ensure that all screw holes are aligned properly.
4. Attach (1) wire management trough to partition / support panel using (5) #10 X 5/8 screws.
5. insert (2) grommets, (1) in each end.