

LEARNING WALL INSTALLATION INSTRUCTIONS

Items needed:

- Hand Drill
- Screwdriver
- 1/8" diameter Drill Bits
- Level

1. Lower Base Unit Installation

- Place the Lower Base Units in desired location and level them.
- Where the Lower Base Units come together find the four pre-drilled 5/16 diameter holes (two towards Top and two approx. 5 1/4" up from the Bottom) and connect them using 4 sleeve connectors.

2. Upper Shelving Unit Installation

- Place the Upper Shelving Units on their corresponding Lower Base Units, flush on the Ends and Back edges. In the same fashion as above where the units come together connect by using 4 sleeve connectors. To accomplish this find the four pre-drilled 5/16 diameter holes (two towards Top and two 5" up from the Bottom) and connect them using 4 sleeve connectors.

- Ⓑ - Attachment of the Upper Shelving Units to the Lower Base Units is accomplished by locating the pre-drilled countersunk holes provided in the Bottom of each Shelving Unit. Using these holes as a guide, drill a 1/8" diameter hole through the Lower Base Unit Top. Secure the Shelving Units to the Base Units using #10 X 1 1/4 flat head screws.

3. Sliding Board Installation


- Prior to installation mount the Markerboard Carrier, 2 per board. Make sure the mounting slot faces the Hutch Unit.
- Position the Bottom Track onto the Lower Base Unit centered left to right and flush to the front edge (see drawing for clarification). Pre-drill holes and mount the Bottom Track using #8 X 5/8 flat head screws.
- Position and clamp the Top Track to the underside of the Top and centered left to right directly above and parallel to the Bottom Track; this should be approximately 1/8" in from the front of the Hutch Top (see drawing for clarification). Pre-drill holes and mount the Top Track under the Hutch Top using #8 X 5/8 pan head screws.
- Mount Sliding Markerboards to Carriers.

4. End Panel Installation

- Mount the End Panel by lining up inserts with the pre-drilled hole in the Upper and Lower Units. Secure using 1/4-20 X 1 1/4" bolts, 8 per End Panel.

5. Bumper Installation

- Place one Bumper per track on each End Panel 3" up from the Bottom Track using #8 X 5/8 pan head screws.



B	REVISED NOTE, 02/22/13 RS	
A	REVISED PICTORIALY, 06/20/08 RG	SCALE 1:4
FLEETWOOD GROUP, INC. FURNITURE DIVISION		
11832 JAMES ST., HOLLAND, MI. P.O. BOX 1259 49422-1259 PHONE (616) 396-114 FAX (616) 396-8022		
DRAWN	CHECKED	DESCRIPTION
renees	jeffb	LEARNING WALL INSTRUCTIONS
DATE	DATE	PART NO.
06/14/07	2/22/2013	60.XTRK-INSTA