


8" HIGH TABLE TOP CARREL ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED:

RUBBER Mallet



PAGE 1


8" HIGH TABLE TOP CARREL ASSEMBLY INSTRUCTIONS

STEP #1:

LOCATE BACK PANEL. ATTACH BACK TO THE RIGHT HAND END PANEL. THIS IS DONE BY HOLDING THE END IN AN UPRIGHT POSITION. (NOTE THE MODULAR CLIPS LOCATED IN THE EDGE OF THE BACK PANEL.) SLIP THE MODULAR CLIPS OVER THE TWO SHOULDER SCREWS LOCATED NEAR THE BACK EDGE OF THE END PANEL. ONCE THE MODULAR CLIPS HAVE BEEN SLIPPED OVER THE SHOULDER SCREWS, SLIDE THE BACK PANEL DOWNWARD, USE THE RUBBER Mallet TO SLIDE THE BACK AN ADDITIONAL 1/2" TO SEAT THE MODULAR CLIPS. NOTE: WHEN MODULAR CLIPS HAVE BEEN PROPERLY SEATED, THE TOP EDGE OF THE BACK PANEL WILL BE FLUSH WITH THE TOP EDGE OF THE END. REPEAT THIS STEP TO INSTALL THE LEFT HAND END PANEL.

STEP #2:

LOCATE PARTITION PANEL. ATTACH PARTITION TO THE BACK PANEL. THIS IS DONE BY FLIPPING THE BACK AND END PANEL ASSEMBLY UPSIDE DOWN. (NOTE THE MODULAR CLIPS LOCATED IN THE BACK EDGE OF THE PARTITION.) SLIP THE MODULAR CLIPS OVER THE TWO SHOULDER SCREWS LOCATED ON THE INSIDE FACE OF THE BACK PANEL. ONCE THE MODULAR CLIPS HAVE BEEN SLIPPED OVER THE SHOULDER SCREWS AND THE PARTITION SLID DOWNWARD, USE THE RUBBER Mallet TO SLIDE THE PARTITION AN ADDITIONAL 1/2" TO SEAT THE MODULAR CLIPS. NOTE: WHEN MODULAR CLIPS HAVE BEEN PROPERLY SEATED, THE TOP EDGE OF THE BACK PANEL WILL BE FLUSH WITH THE TOP EDGE OF THE PARTITION.



PAGE 2