




1. Attach end assemblies (2, 3) to back (1) with #10 x 5/8" pan head screws (12) (see Detail A)
2. Attach top assembly (4) and bottom assembly (5) to ends (2, 3) and back (1) with #10 x 5/8" pan head screws (12) (see Detail B)
3. Attach top / bottom support tubes (6) to ends (2, 3) with #10 x 3/4" pan head screws (13) (see Detail C)
4. Attach toe kick (7) to ends (2, 3) and bottom (5) with #10 x 5/8" pan head screws (12) (see Detail D)
5. Attach support tubes (8) to support tube brackets (9) with 1/4-20 bolt / wing nut (14, 15) (Note: carpet seam down) (see Detail E)
- *If your cabinet was purchased with doors proceed to #6
6. Attach door assemblies (10, 11) to ends (2, 3) with #8 x 5/8" flat head screws (16) (see Detail F)




DETAIL A




DETAIL B




DETAIL C



DETAIL E



DETAIL D



DETAIL F

