


# CLASSROOM 13" DP HUTCH ADDITION MOUNTING INSTRUCTIONS



## HARDWARE REQUIRED:

6 - #12 X 5/8" MOD-EEZ SCREWS  
(INCLUDED W/ HUTCH UNIT)

NOTE: UNIT / HUTCH SHOWN MAY DIFFER

## TOOLS REQUIRED:

ELECTRIC DRILL / DRIVER  
5/32" DRILL BIT  
PHILLIPS SCREW DRIVER OR BIT  
TAPE MEASURE  
RUBBER MALLET


\\NTCOMSRV3\SOLIDEDGE\Solid Edge Parts\Specials\52435-99\52435-99inst.asm

PAGE 1

# CLASSROOM 13" DP HUTCH ADDITION MOUNTING INSTRUCTIONS

## STEP #1:

MEASURE AND DRILL 6 HOLES 5/32" DIA. X 5/8" DP. INTO LOW CABINET TOP.  
SEE DIAGRAM A




**DIAGRAM A**

# CLASSROOM 13" DP HUTCH ADDITION MOUNTING INSTRUCTIONS

## STEP #2:

SCREW THE 6 - #12 X 5/8" MOD-EEZ SCREWS INTO THE HOLES THAT WERE DRILLED IN STEP 1. MAKE SURE THE SCREWS ARE SEATED FLUSH TO TOP. SEE DIAGRAM B




**DIAGRAM B**

# CLASSROOM 13" DP HUTCH ADDITION MOUNTING INSTRUCTIONS

## STEP #3:

PLACE HUTCH ADDITION ON TOP OF LOWER CABINET TOP, OVER PROTUDING CONNECTING SCREWS. HUTCH SHOULD OVERHANG BACK BY 1/2". SEE DIAGRAM C. SLIDE HUTCH ADDITION FORWARD BY PUSHING ON BOTTOM OF HUTCH ADDITION. A RUBBER MALLET MAY BE NECESSARY TO FULLY ENGAGE HUTCH ADDITION W/ LOWER CABINET. ASSEMBLED UNIT SHOULD HAVE 1/2" SPACE IN BACK AND 1 1/2" SPACE ON ENDS.



**DIAGRAM C**