



Bolt on Leg Assembly Instructions

126900-INST
Rev. B

1. Place the worksurface upside down on a non-scratching surface. Place the legs onto the worksurface and align the holes in the top plate of each leg with the pilot holes in the worksurface. (NOTE: Adjustable height leg with casters shown. Your product may not include adjustable legs or casters.)



2. Insert (9) #10 x .875" screws through the holes in the top plate of each leg and into the pilot holes in the worksurface. Tighten to a torque of 30 to 35 in-lb.



For questions please call us at (616) 396-1142