



DESCRIPTION

STACK TABLES

NO.

PC.S2000 - INST

SE

1. **ASSEMBLY NOTE: (2) SHORTER 2 1/4" SCREWS MUST ONLY BE USED IN PLACE SHOWN (\*) OR TOP DAMAGE WILL OCCUR.**
2. ATTACH TOP TO FRAME BY SETTING SPACERS #C0948-700 (6) ONTO TOP OF FRAME. SET TOP ON THESE SPACERS AND INSERT (4) #606531 2 1/2" SCREWS THRU (4) #606709 WASHERS AND (4) A0473-702 BUMPERS. ATTACH THRU FRAME AND SPACERS AS SHOWN AND SCREW INTO TOP HOLES.
3. INSERT (2) #606529 2 1/4" SCREWS THRU FRAME AND SPACERS AS SHOWN AND SCREW INTO TOP.
4. POUND IN (2) #B1380-700 TUBE CAPS AS SHOWN.
5. POUND IN (4) #735350 LEVELER INSERTS AND SCREW IN (4) 731020 GLIDES.

