

NOTE

ATTENTION INSTALLER:
THIS HUTCH CABINET MUST BE
ATTACHED TO A BASE CABINET TOP

PRE - DRILL BASE CABINET TOP
WITH 9/64" DRILL BIT AND ATTACH
HUTCH CABINET WITH 4 - #10 X 1 1/2"
TRUSS HEAD SCREWS