

ILLUSION LOCK OPTION

84" HIGH UNITS

LOCK INSTALLATION

A. SLIDE LOCK - PREDRILL FOUR 1/8" DIA. X 1/2" DEEP HOLES ON THE TOP INSIDE OF THE LEFT HAND DOOR. ATTACH THE SLIDE LOCK, USING #8 X 5/8" PAN HEAD SCREWS. (FIG. 1)

B. CAM LOCK - LOCATE THE CENTER OF YOUR LOCK HOLE USING THE PRINT SHOWN ON (FIG. 2). CLAMP A PIECE OF SCRAP TO THE INSIDE OF THE DOOR WHERE THE DRILL BIT WILL EXIT, TO AVOID CHIPPING. USING A 3/4" BIT, DRILL OUT THE LOCK HOLE ALL THE WAY THROUGH THE DOOR. REMOVE SCRAP PIECE AND INSERT THE LOCK INTO THE HOLE. ATTACH THE NUT, CAM, CAM WASHER AND CAM SCREW, AS SHOWN (FIG 3).

FIG. 1




FIG. 2





FIG. 3



*NOTE: BEFORE THE CAM SCREW HAS BEEN TIGHTENED, BE SURE YOUR CAM IS FACE DOWN IN THE UNLOCK POSITION WHEN THE KEY IS AT THE 9:00 O'CLOCK POSITION. THE KEY THEN TURNS TO THE RIGHT IN THE 12:00 O'CLOCK POSITION WHEN CAM IS IN THE LOCKING POSITION.