


SINGLE BED ASSEMBLY INSTRUCTIONS

Bed assembly

Begin by taking eight tube caps #6 and two foot/end boards #2, using a rubber mallet pound the tube caps #6 into the upper and lower ends of each leg. Next mount the spring frame #1 to the two foot/end boards #2 using eight each of the 5/16" hardware #3 #4 #5. Tighten the hardware using a 1/2" wrench or socket.

TOOLS REQUIRED:
 - 1/2" Wrench Or 1/2"
 Hex Drive Socket
 - Rubber Mallet



PARTS LIST		
NO.	QTY.	PART DESCRIPTION
1	1	SPRING FRAME
2	2	FOOT / HEAD BOARD
3	8	3/8-16 x 3/4" ZINC CARRIAGE BOLT
4	8	3/8" FLAT WASHER
5	8	3/8-16 LOCK NUT
6	8	TUBE CAP